

REPAIR PARTS




Fig. 11

Key No.	Part No.	Description
1	M-0034R	Sheperd's Hook
2	M-0039R	Upper Pole
3	Q-0015 R	Collar
4	M-0040R	Lower Pole
5	N-0015	Setscrew
6	G-0043	Ground Stake
7	P-0019	Wire Handle
8	L-0032R	Fixture Top
9	NI-MH3(60)	NIMH Battery
10	L-0033	Battery Cover
11	J-0036	Small Glass Panel
12	J-0037	Large Glass Panel
13	N-0020	Setscrew
14	H-0054R	Lower Housing
15	N-0015	Setscrew
16	M-0036R	11 3/4"L Square Post
17	S-0029	Reflector

TWILIGHT
SOLAR
OUTDOOR LIGHTING®

**MODEL NO.
CSNA-7**

SOLAR LANDSCAPE LIGHT

CAUTION:

Solar light enclosed contains glass panels, be careful not to drop fixture--glass may break.

THIS PACKAGE CONTAINS 1 EACH OF THE FOLLOWING: (SEE FIGURE 11, PAGE 4)

- A. Solar light w/3 AAA nickel-metal hydride (NiMH) rechargeable batteries.
- B. Shepherd's hook.
- C. 9 1/2" L Upper Round Pole With Collar.
- D. 8 7/8" L Lower Round Pole.
- E. 11 3/4" L Square Post.
- F. Ground Stake.